

**Assembly Instructions**  
**FJ-60 Transfer Case Parking Brake**

**Installation Instructions**

1. Install the rotor on the backside of the yoke using the 7/16 bolts, flat washers and lock nuts.
  
2. Bolt the bracket to the case. Seal the threads on the bolts into the case. ( The bracket can mount in any position, but was designed to go at the top with the cable bracket going to the right. )
  
3. Install the caliper to transfer case bracket on the caliper.
  
4. Mount the caliper to the transfer case bracket. Use the 7/16-20 X 1 1/2 bolts, flat washers, and lock nuts.