

Assembly Instructions Rockwell Parking Brake

Installation Instructions

1. Install the rotor on the backside of the yoke using the 3/8-24 bolts and nuts
2. Bolt the bracket to the case. Seal the threads on the bolts into the case.
3. Install the caliper to transfer case bracket on the caliper.
4. Mount the caliper to the transfer case bracket.