

Assembly Instructions International Parking Brake

Installation Instructions

1. Install the rotor on the backside of the yoke using the 5/16-24 bolts and washers. The bolts are a little long so use a couple of washers.
2. Bolt the bracket to the case using the 9/16 bolts and lock washers.
3. Install the caliper to the bracket. Use the extra 7/16 washers to space the caliper in relation to the rotor.